

## Chapter 22

# Connecting to Remote Hosts from the SRC Software

This chapter describes how to connect to a remote host from the SRC CLI through SSH or Telnet. Topics include:

- Connecting to a Remote Host Through SSH on page 195
- Connecting to a Remote Host Through Telnet on page 195

### Connecting to a Remote Host Through SSH

---

To connect to a remote host through SSH:

- In operational mode, enter the following command.

```
user@host> ssh host host <v1 | v2>
```

where:

- *host*—Hostname or IP address of the remote host. You can specify a username by using the format *user@host* for *host*. If you do not specify a username, the command uses the username of the current user.
- <v1 | v2>—Version of SSH, 1 or 2.

### Connecting to a Remote Host Through Telnet

---

To connect to a remote host through Telnet:

- In operational mode, enter the following command.

```
user@host> telnet host <port port>
```

where:

- *host*—Hostname or IP address of the remote host.
- **port port**—(Optional) Port number or service name on the remote host.

