

Chapter 6

Using JUNOSe Routers in the SRC Network with a Solaris Platform

This chapter describes how to set up the SRC software on a Solaris platform with the SRC configuration applications that run only on Solaris platforms. It also shows how to set up a JUNOSe router so that the router can be used the SRC network. It includes information about how to monitor the interactions between the SAE and the JUNOSe router and how to troubleshoot SRC problems on the router.

You can also use the following to configure JUNOSe routers:

- To use the SRC CLI, see *Chapter 5, Using JUNOSe Routers in the SRC Network with the SRC CLI*.
- To use the C-Web interface, see *SRC-PE C-Web Interface Configuration Guide, Chapter 17, Using JUNOSe Routers in the SRC Network with the C-Web Interface*.

Topics in this chapter include:

- COPS Connection Between JUNOSe Routers and the SAE on page 68
- Adding JUNOSe Routers and Virtual Routers on page 68
- Configuring the SAE to Manage JUNOSe Routers on page 76
- Using SNMP to Retrieve Information from JUNOSe Routers on page 76
- Developing Router Initialization Scripts on page 77
- Specifying Router Initialization Scripts on the SAE on page 80
- Updating Local IP Address Pools for JUNOSe VRs on page 80
- Accessing the Router CLI on page 83
- Starting the SRC Client on a JUNOSe Router on page 85
- Stopping the SRC Client on a JUNOSe Router on page 86
- Monitoring Interactions Between the SAE and the JUNOSe Router on page 86
- Troubleshooting the SRC Client on JUNOSe Routers on page 87

COPS Connection Between JUNOSe Routers and the SAE

Configuring the SRC client on a JUNOSe router opens a Common Open Policy Service (COPS) protocol layer connection to the SAE. When the SRC client software establishes a TCP/IP connection to the SAE, the SAE starts to manage the JUNOSe router. Subsequently, the SRC client sends configuration changes made on the JUNOSe router to the SAE, and the SAE updates SRC configurations for services and policies accordingly.

The SAE supports two versions of COPS:

- COPS usage for policy provisioning (COPS-PR)
- COPS External Data Representation Stand (COPS XDR)

The version of COPS that you use depends on the version of COPS that your JUNOSe router supports. When you set up your JUNOSe router to work with the SAE, you enable either COPS-PR mode or COPS XDR mode.

Highly Available Connections to JUNOSe Routers

JUNOSe routers maintain state information, a feature that allows an active, managing SAE to reconnect to a JUNOSe router without a performing a data resynchronization in the following instances:

- The network connection between the SAE and the JUNOSe router is disrupted, and the router reconnects to the SAE
- For JUNOSe routers with high availability configured, when the secondary SRP takes control from a failed SRP it can reconnect to the SAE

Adding JUNOSe Routers and Virtual Routers

The SAE uses router and virtual router objects in the directory to manage interfaces on JUNOSe virtual routers. Each JUNOSe router in the SRC network and its virtual routers (VRs) must appear in the directory. There are two ways to add routers to the directory:

- Use SDX Admin to detect operative routers and configured JUNOSe VRs in the SRC network and add them to the directory.
- Add each router and VR individually. You need to add routers and VRs individually if you use an LDAP client other than SDX Admin or if you want to add inoperative routers or unconfigured JUNOSe VRs.



NOTE: You must define connected SAEs for each router in the virtual router object of the directory. This step is required for the SAE to work with the router. See *Specifying the SAEs That Can Manage the Router* on page 75.

Adding Operative JUNOSe Routers and Virtual Routers

To simultaneously add to the directory routers and JUNOSe VRs that are currently operative and have an operating Simple Network Management Protocol (SNMP) agent:

1. In the SDX Admin navigation pane, select **o = Network**, and right-click.
2. Select **Discover Network**.

The Discover Network dialog box appears.

3. Enter the IP address, the prefix of the network, and the SNMP community string.
4. Click **OK**.

Objects for all routers and JUNOSe VRs that meet the criteria you specified appear under the Networks object in the navigation pane. You can modify the configuration of these objects. For information about configuring these objects, see *Adding Routers Individually* on page 69 and *Adding Virtual Routers Individually* on page 71.

Adding Routers Individually


To add a single router to the directory with SDX Admin:

1. In the navigation pane, right-click the **Network** folder, and select **New > EdgeDevice**.

The New EdgeDevice dialog box appears.

2. Enter the name of the router exactly as it is configured on the router, and click **OK**.

The name of the new device appears in the navigation pane, and information about the router appears in the Main Tab of the EdgeDevice pane.



3. In the content pane, edit or accept the default values for the router fields.

See *Router Fields* on page 70.

4. Click **Save**.

Router Fields

In SDX Admin, you can modify the following fields in the content pane for a router (*orderedCimKeys* = < *EdgeDeviceName* > , *o* = *network*, *o* = *umc*).

Description

- Information about this device; keywords that the find utility uses.
- Value—Text string
- Example—ERX-1400 router located in Ottawa

Management Address

- IP address of the router. If you add a router using the discover network feature, the software automatically adds the IP address of the first SNMP agent on the router to respond to the discover request.
- Value—IP address
- Example—192.0.1.1

Router Driver Type

- Type of device that this router object will be used to manage.
- Value
 - JUNOSe—JUNOSe router
 - JUNOS—JUNOS routing platform
 - PCMM—CMTS device
- Default—No value

QoS Profiles

- For JUNOSe routers, specifies quality of service (QoS) profiles that are configured on the router. To update this list, see *SRC-PE Solutions Guide, Chapter 1, Managing Tiered and Premium Services with QoS on JUNOSe Routers with the SRC CLI*.
- Value—List of QoS profiles on separate lines
- Guideline—This field applies to JUNOSe routers only
- Example—atm-default

Adding Virtual Routers Individually


To add a VR to the directory with SDX Admin:

1. In the navigation pane, right-click the device to which you want to add the VR, and select **New > VirtualRouter**.

The New VirtualRouter dialog box appears.

2. Enter the name of the VR, and click **OK**.
 - For JUNOSe routers, the name of the VR, which is case sensitive, must exactly match the name of the VR configured on the router.
 - For JUNOS routing platforms and CMTS devices, use the name default.

The name of the new VR appears in the navigation pane, and the VirtualRouter pane appears.



3. In the Main tab in the VirtualRouter pane, edit or accept the default values for the fields.

See *Virtual Router Fields* on page 72.

4. Select the **SAE Connection** tab in the VirtualRouter pane, and add SAEs that are connected to the router.

See *Specifying the SAEs That Can Manage the Router* on page 75.



NOTE: This step is required for the SAE to work with the router.

5. Click **Save**.

Virtual Router Fields

In SDX Admin, you can modify the following fields in the content pane for a virtual router (*virtualRouterName* = < *virtualRouterName* = < name of virtual router > *orderedCimKeys* = < *EdgeDeviceName* > , *o* = *network*, *o* = *umc*).

SNMP Read Community

- SNMP community name associated with SNMP read-only operations for this VR.
- Value—Text string
- Example—admin

SNMP Write Community

- SNMP community name associated with SNMP write operations for this VR.
- Value—Text string
- Example—public

Scope

- Service scopes assigned to this VR.
- Value—Text string
- Example—POP-Westford

Local Address Pools

- List of IP address pools that a JUNOSe VR currently manages and stores.
- Value—You can specify an unlimited number of ranges of local IP address pools for JUNOSe VRs. You can specify either the first and last addresses in a range or the first IP address and a factor that indicates the start of the range. You can also specify IP addresses to exclude. Use spaces in the syntax only to separate the first and last explicit IP addresses in a range.

The IP pool syntax has the format:

```
([<ipAddressStart> <ipAddressEnd>] |
{<ipBaseAddress>/(<mask> | <digitNumber>)(,<ipAddressExclude>)*})
```

where:

- <ipAddressStart> —First IP address (version 4 or 6) in a range
- <ipAddressEnd> —Last IP address (version 4 or 6) in a range
- <ipBaseAddress> —Network base address
- <mask> —IP address mask
- <digitNumber> —Integer specifying the number of significant digits of the first IP address in the range
- <ipAddressExclude> —List of IP addresses to be excluded from the range
- | —Choice of expression; choose either the expression to the left or the expression to the right of this symbol
- * —Zero or more instances of the preceding group
- Guidelines—If you do not configure the **PoolPublisher** router initialization scripts for a JUNOSe router, configure this field for the JUNOSe VR.
- Default—No value
- Example—This example shows four ranges for the IP address pool.

```
([10.10.10.5 10.10.10.250]
{10.20.20.0/24}
{10.21.0.0/255.255.0.0})
```

{10.20.30.0/24,10.20.30.1})

- The first range (a simple range) specifies all the IP addresses between the two IP addresses 10.10.10.5 and 10.10.10.250.
- The second range specifies all the IP addresses in the range 10.20.20.0 to 10.20.20.255.
- The third range uses a network mask to specify all the IP addresses in the range 10.21.0.0 to 10.21.255.255.
- The fourth range specifies all the addresses of the network 10.20.30.0 to 10.20.30.255, excluding the address 10.20.30.1.

Static Address Pools

- List of IP address pools that a JUNOS VR manages but does not store. You can configure these address pools only in the SRC software.
- Value—See the field Local Address Pools.
- Guidelines—Configure this field on JUNOS and CMTS VRs only.
- Default—No value
- Example—([10.10.10.5 10.10.10.250] {10.20.20.0/24})

Managing SAE IOR

- Common Object Request Broker Architecture (CORBA) reference for the SAE managing this VR.
- Value—One of the following items:
 - The actual CORBA reference for the SAE
 - The absolute path to the interoperable object reference (IOR) file
 - A corbaloc URL in the form corbaloc:: <host> :8801/SAE
 - <host> is the name or IP address of the SAE host.
- Default—No value
- Guidelines—The **PoolPublisher** and **IorPublisher** router initialization scripts provide this information when the router connects to the SAE. If you do not use one of these router initialization scripts, enter a value in this field.
- Example—One of the following items:
 - Absolute path—/opt/UMC/sae/var/run/sae.ior
 - corbaloc URL—corbaloc::boston:8801/SAE
 - Actual IOR—
IOR:0000000000000002438444C3A736D67742E6A756E697...


Tracking Plug-in

- Plug-ins that track interfaces that the SAE manages on this VR. The SAE calls these plug-in instances for every interface it manages. The SAE calls these plug-ins after an interface comes up, when new policies are installed on the interface, and when the interface goes down.

- Value—Comma-separated list of plug-in instances
- Guidelines—Enter plug-in instances and network information collector (NIC) SAE plug-in agents that are specific to this VR.
- Default—No value
- Example—nicsae, flexRadius

Specifying the SAEs That Can Manage the Router

You must add the addresses of SAEs that can manage this router. This step is required for the SAE to work with the router. To add the SAEs, select the SAE Connection tab in the VirtualRouter pane.



Adding an SAE

To add an SAE:

1. Type the IP address of the SAE in the field below the Connected SAE box.

To specify the active SAE and the redundant SAE, enter an exclamation point (!) after the hostname or IP address of the connected SAE.
2. Click **Add**.

Modifying an SAE Address

To modify an SAE address:

1. Click the IP address of the SAE in the Connected SAE box.
2. Modify the IP address in the field below the Connected SAE box.
3. Click **Modify**.

Deleting an SAE Address

To delete an SAE address:

1. Click the IP address of the SAE in the Connected SAE box.
2. Remove the IP address from the field below the Connected SAE box.
3. Click **Delete**.

Connected SAE

- SAEs that are connected to the router or CMTS device.
- Value—IP addresses
- Default—No value

Configuring the SAE to Manage JUNOSe Routers

To set up the SAE to manage JUNOSe routers, you need to configure a router driver that specifies the COPS connection between the SAE COPS server and the COPS client in the JUNOSe router. See *Chapter 5, Using JUNOSe Routers in the SRC Network with the SRC CLI*.

Using SNMP to Retrieve Information from JUNOSe Routers

Some scripts in the SRC software use SNMP to get information from the router. For example, the **poolPublisher** router initialization script uses SNMP to read the IP pools.

- On the router, you can configure access to the router's SNMP server. See *Configuring the SNMP Server on the JUNOSe Router* on page 77.
- On the SAE, you can configure global default SNMP communities that are used for read and write access to the router. See *Configuring Global SNMP Communities in the SRC Software* on page 77.
- In the directory, you can specify SNMP communities for each virtual router. We recommend that you specify communities for each virtual router instead of global communities. See *Adding Virtual Routers Individually* on page 71.

Configuring the SNMP Server on the JUNOSe Router

Access to the SNMP server on the router by an SNMP client is governed by a proprietary SNMP community table. This table identifies communities that have read-only, read-write, or administrative permission to the SNMP Management Information Base (MIB) stored on a particular server.

When an SNMP server receives a request, the server extracts the client's IP address and the community name. The SNMP server searches the community table for a matching community.

- If a match is found, its access list name is used to validate the IP address.
 - If the access list name is null, the IP address is accepted.
 - If an invalid IP address results, an SNMP authentication error is sent to the SNMP client.
- If a match is not found, an SNMP authentication error results.

To configure the SNMP agent on the JUNOSe router:

1. Switch to the virtual router for which you want to create an SRC client.

```
host1#(config)virtual-router <vrName>
```

2. Enable the SNMP agent.

```
host1:<vrName>#(config)snmp-server
```

3. Configure at least one authorized SNMP read-write community (SNMPv1/v2c), which provides SNMP client access.

```
host1:<vrName>(config)#snmp-server community boston rw
```

4. (Optional) Configure a read-only community.

```
host1:<vrName>#(config)snmp-server public ro
```

Configuring Global SNMP Communities in the SRC Software

You can configure global default SNMP communities that are used if a VR does not exist on the router or the community strings have not been configured for the VR. See *Chapter 5, Using JUNOSe Routers in the SRC Network with the SRC CLI*.

Developing Router Initialization Scripts

When the SAE establishes a connection with a router, it can run a router initialization script to customize the setup of the connection. Router initialization scripts are run when the connection between a router and the SAE is established and again when the connection is dropped.

For JUNOS VRs that supply IP addresses from a local pool, a router initialization script is provided that identifies which VR supplies each IP pool and writes the information to the directory. The SAE runs the script only when a COPS connection is established to the JUNOS router. Consequently, if you modify information about IP pools on a VR after the COPS connection is established, the SAE will not automatically register the changes, and you must update the directory.

Table 6 describes the router initialization scripts that we provide with the SRC software in the */opt/UMC/sae/lib* directory.

Table 6: Router Initialization Scripts

Script Name	Function	When to Use Script
lorPublisher	Publishes the IOR of the SAE in the directory so that a NIC can associate a router with an SAE.	Use with JUNOS routers that do not supply IP addresses from local pools, and JUNOS routing platforms.
poolPublisher	Publishes the IOR of the SAE and local IP address pools in the directory so that a NIC can associate a router with an SAE and resolve the IP-to-SAE mapping.	Use with JUNOS virtual routers that supply IP addresses from local pools.

Interface Object Fields

Router initialization scripts interact with the SAE through an interface object called `Ssp`. The SAE exports a number of fields through the interface object to the script and expects the script to provide the entry point to the SAE.

Table 7 describes the fields that the SAE exports.

Table 7: Exported Fields

Ssp Attribute	Description
<code>Ssp.properties</code>	System properties object (class: <code>java.util.Properties</code>)—The properties should be treated as read-only by the script.
<code>Ssp.errorLog</code>	Error logger—Use the <code>Ssp.errorLog.println (message)</code> to send error messages to the log.
<code>Ssp.infoLog</code>	Info logger—Use the <code>Ssp.infoLog.println (message)</code> to send informational messages to the log.
<code>Ssp.debugLog</code>	Debug logger—Use the <code>Ssp.debugLog.println (message)</code> to send debug messages to the log.

The router initialization script must set the field `Ssp.routerInit` to a factory function that instantiates a router initialization object:

- `<VRName>` —Name of the virtual router in which the COPS client has been configured, format: `virtualRouterName@RouterName`
- `<virtIp>` —Virtual IP address of the SAE (string, dotted decimal; for example: `192.168.254.1`)
- `<realIp>` —Real IP address of the SAE (string, dotted decimal; for example, `192.168.1.20`)

- `<VRIp>` —IP address of the virtual router (string, dotted decimal)
- `<transportVR>` —Name of the virtual router used for routing the COPS connection, or None, if the COPS client is directly connected

The factory function must implement the following interface:

```
Ssp.routerInit(VRName,
virtualIp,
realIp,
VRIp,
transportVR)
```

The factory function returns an interface object that is used to set up and tear down a connection for a given COPS server. A common case of a factory function is the constructor of a class.

The factory function is called directly after a COPS server connection is established. In case of problems, an exception should be raised that leads to the termination of the COPS connection.

Required Methods

Instances of the interface object must implement the following methods:

- `setup()`—Is called when the COPS server connection is established and is operational. In case of problems, an exception should be raised that leads to the termination of the COPS connection.
- `shutdown()`—Is called when the COPS server connection is terminated to the virtual router. This method should not raise any exceptions in case of problems.

Example: Router Initialization Script

The following script defines a router initialization class named *SillyRouterInit*. The interface class does not implement any useful functionality. The interface class just writes messages to the infoLog when the router connection is created or terminated.

```
class SillyRouterInit:
    def __init__(self, vrName, virtualIp, realIp, vrIp, transportVr):
        """ initialize router initialization object """
        self.vrName = vrName
        Ssp.infoLog.println("SillyRouterInit created")

    def setup(self):
        """ initialize connection to router """
        Ssp.infoLog.println("Setup connection to VR %(vrName)s" %
            vars(self))

    def shutdown(self):
        """ shutdown connection to router """
        Ssp.infoLog.println("Shutdown connection to VR %(vrName)s" %
            vars(self))
```

```
#
# publish interface object to Ssp core
#
Ssp.routerInit = SillyRouterInit
```

Specifying Router Initialization Scripts on the SAE

To specify router initialization scripts, see *Chapter 5, Using JUNOS Routers in the SRC Network with the SRC CLI*.

Updating Local IP Address Pools for JUNOS VRs

When you reconfigure local IP address pools on a JUNOS VR, you must update in the directory the local IP addresses that the VR provides.

Before you update local IP address pools, make sure that:

- The JUNOS router and VR appear in the directory.
- The VR has an operating SNMP agent.
- The host that supports SDX Admin or the SAE can communicate with the VR through SNMP.
- You have write permissions for the *o = Network* subtree.

There are two ways to add routers to the directory:

- SDX Admin—Updates on VR at a time.
- The **poolRepublish** command—simultaneously updates any number of VRs in the same directory.

Updating Local IP Address Pools with SDX Admin

To allow updates of IP address pools with SDX Admin, the host that supports SDX Admin must be able to communicate with the VR through SNMP. To update local IP address pools for a VR in the directory with SDX Admin:

1. In the navigation pane, expand **o = Network**.
2. In the navigation pane, expand the object for the router on which the VR is configured.
3. Right-click the object for the VR in the navigation pane.
4. Select **Update IP Pools**.

The SDX Admin dialog box appears.

5. Enter the IP address for the VR, enter the SNMP community if the default value is incorrect, and click **OK**.

SDX Admin updates the local IP addresses for the VR in the directory and displays the information in the Local IP Address field of the Main tab in the VirtualRouter pane.

Updating Local IP Address Pools with the `poolRepublish` Command

You can use the `poolRepublish` command on the SAE host to update local IP address pools. You can specify multiple VRs with the `poolRepublish` command that use the same SNMP read community. For each VR you must specify the name of the VR, the name of the JUNOSe router on which it is configured, the VR's corresponding IP address, and the directory connection.

To update local IP addresses using the `poolRepublish` command:

1. On the SAE host, access the folder `/opt/UMC/sae/etc`.

```
cd /opt/UMC/sae/etc
```

2. Run the command.

```
./poolRepublish -v vr1@erx1 -i 192.0.2.1 -v vr2@erx2 -i 192.0.2.3 -h 192.0.2.5  
-w admin123 -D cn=umcAdmin,o=umc -b o=Network,o=umc -c public
```

The software updates and displays the local IP address pools for each VR you specified.

```
vr1@erx1 pools: ([10.227.11.242 10.227.11.250][10.227.11.226  
10.227.11.239]{10.227.11.208/255.255.255.240}{10.227.11.240/255.255.2  
55.240}{10.227.11.224/255.255.255.240})  
vr2@erx2: ([10.227.12.242 10.227.12.250][10.227.12.226  
10.227.12.239]{10.227.12.208/255.255.255.240}{10.227.12.240/255.255.2  
55.240}{10.227.12.224/255.255.255.240})
```

Syntax of `poolRepublish` Command

The syntax for the `poolRepublish` command is:

```
poolRepublish { { -v <vrName> @ <routerName> -i <ipAddress> } *  
-h <host> -b <baseDn> -D <bindDN> -w <password>  
-c <readCommunity> } | -H }
```

<vrName>

- Name of the VR.
- Value—Text string (value is case sensitive and must match the name in the JUNOSe configuration)
- Guideline—You must enter a value for this property.
- Example—vr-boston

<routerName>

- Name of JUNOSe router on which VR is configured.
- Value—Text string (value is case sensitive and must match the name in the JUNOSe configuration)
- Example—`erx1`

<ipAddress>

- VR's IP address.
- Value—IP address or text string
- Example—`192.0.2.1`

<host>

- IP address or name of the host that supports the directory.
- Value—IP address or text string
- Example—`192.0.2.2` or `ottawa`

<baseDn>

- DN of the root of the tree in the directory.
- Value—DN
- Example—`o = Network, o = umc`

<bindDn>

- DN of the username for authentication with the directory server.
- Value—DN
- Example—`cn = umcAdmin, o = umc`

<password>

- Password for authentication with the directory server.
- Value—Text string
- Example—`Admin123`

<readCommunity>

- Name of the SNMP read community for the VR. If the SNMP read community for a VR is defined in the directory, you do not need to specify this value.
- Value—Text string
- Example—`public`

-H

- Displays help for this tool.

Troubleshooting the **poolRepublish** Command

You must specify the correct arguments for the **poolRepublish** command. In addition, the specified router and directory must be available for the command to run successfully.

If no SNMP read community is configured in the directory for the VR and you do not specify this value when you run the **poolRepublish** command, you will see the following error message:

Could not perform ip pools update due to No 'snmpReadCommunity' attribute is provided for virtual router: vr1@bigfoot

If you run the **poolRepublish** command again and supply this SNMP read community, the command should run correctly.

Accessing the Router CLI

You can access the CLIs of Juniper Networks routers from Policy Editor and from SDX Admin through a Telnet or SSH connection. This access allows you to display and change the configuration of the router.


You must have the Telnet or SSH applications installed and available to Policy Editor or SDX Admin. You can open multiple Telnet or SSH sessions.

Using Policy Editor

To access a router from Policy Editor:

1. In the Policy Editor window, click **Tools** in the menu bar; then click **Manage**.

The Remote Access dialog box appears.



The image shows a 'Remote Access' dialog box with a title bar. It contains four input fields: 'Address', 'Port Number', 'Protocol' (a dropdown menu currently showing 'telnet'), and 'Login Name'. At the bottom of the dialog are two buttons: 'OK' and 'Cancel'.

2. Fill in the Remote Access fields, and click **OK**.

See *Remote Access Fields* on page 84.


A Telnet or an SSH window with a CLI prompt appears.

Using SDX Admin

To access a router from SDX Admin:

1. In the navigation pane, expand **o = Network**.
2. Select the router to which you want to connect, and right-click.
3. Select **Manage**.

The Remote Access dialog box appears.



4. Fill in the Remote Access fields, and click **OK**.

See *Remote Access Fields* on page 84.

A Telnet or an SSH window with a CLI prompt appears.

Remote Access Fields

In Policy Editor, you can edit the following fields in the Remote Access dialog box, in the Tools > Manage menu.

In SDX Admin, you can edit the following fields in the Remote Access dialog box by right-clicking on the router object, and selecting Manage.

Address

- IP address or hostname of the router.
- Value—IP address
- Default—No value
- Example—192.0.2.1

Port Number

- TCP port over which you want to connect to the router.
- Value—TCP port
- Default—No value
- Example—22

Protocol

- Type of connection
- Value—telnet | ssh
- Default—telnet
- Example—ssh

Login Name

- Login name for SSH connections.
- Value—Text string
- Default—No value
- Guideline—You must enter a value for this property.
- Example—admin

Starting the SRC Client on a JUNOSe Router

JUNOSe routers use an SRC client to interact with the SAE. See *JUNOSe Broadband Access Configuration Guide* for complete information about configuring the SRC client on the JUNOSe router.

To start the SRC client:

1. Access the router CLI.
2. Access Global configuration mode.

```
host1#configure terminal
```

3. Switch to the virtual router for which you want to create an SRC client.

```
host1(config)#virtual-router <vrName>
```

4. Enable the SRC client.

To enable COPS-PR mode:

```
host1:<vrName>(config)#sscc enable cops-pr
```

To enable COPS-XDR mode:

```
host1:<vrName>(config)#sscc enable
```

5. Set the primary address from the configuration directory.

```
host1:<vrName>(config)#sscc primary address <ipAddress> port 3288
```

Stopping the SRC Client on a JUNOSe Router

JUNOSe routers use an SRC client to interact with the SAE. See *JUNOSe Broadband Access Configuration Guide* for complete information about configuring the SRC client on the JUNOSe router.

To stop the SRC client:

1. Access the router CLI.

See *Accessing the Router CLI* on page 83.

2. Access Global configuration mode.

```
host1#configure terminal
```

3. Switch to the virtual router for which you want to stop an SRC client.

```
host1(config)#virtual-router <vrName>
```

4. Disable the SRC client.

```
host1:<vrName>(config)#no ssrc enable
```

Monitoring Interactions Between the SAE and the JUNOSe Router

To monitor the connection between the router and the SAE:

- Use the **show ssrc info** command on the JUNOSe router

To display the version number of the SRC client:

- Use the **show ssrc version** command on the JUNOSe router.

See the *JUNOSe Command Reference Guides* for details about these commands.

You can also monitor the interactions between the SRC software and the router in the log files for the SAE and in the log files generated by the JUNOSe router. For information about configuring logging for the SAE, see *SRC-PE Monitoring and Troubleshooting Guide, Chapter 5, Managing SRC Log Files on a Solaris Platform*. For information about configuring logging on JUNOSe routers, see the *JUNOSe System Event Logging Reference Guide*.

Troubleshooting the SRC Client on JUNOSe Routers

To troubleshoot SRC problems on the router:

1. Look at the log files for the SAE and the log files generated by the SRC client on the JUNOSe router.
 - If the log files indicate a problem with specific interfaces on the router, review the configuration of the associated policies in the SRC software, and fix any errors.
 - If the log files indicate a problem with a specific service or its associated policy rules, review the configuration of the service or policies in the SRC software, and fix any errors.
 - If the log files indicate only that the SRC client is not responding, ensure that the values in the SAE configuration match the values in the SRC client configuration on the router.
2. Restart the SRC client on the JUNOSe router.

When you restart the SRC client, the SRC client removes all policies that were installed by the SRC software and reports all interfaces again.



NOTE: DHCP addresses that were managed are not reported again, so we recommend that you do not restart the SRC client if you are managing DHCP sessions.

To restart the SRC client in COPS-PR mode, enter the following commands:

```
host1:<vrName>(config)#no ssrc enable
host1:<vrName>(config)#sscc enable cops-pr
```

To restart the SRC client in COPS XDR mode, enter the following commands:

```
host1:<vrName>(config)#no ssrc enable
host1:<vrName>(config)#sscc enable
```

If restarting the SRC client does not resolve the problem, rebuild the router configuration and restart the client.

