

## Chapter 6

# Configuring Static Host Mapping with the C-Web Interface

This chapter describes how to configure static host mapping on the Solaris platform or a C-series Controller with the C-Web interface.

You can also configure static host mapping with the SRC CLI. See *SRC-PE Getting Started Guide, Chapter 18, Configuring Static Host Mapping with the SRC CLI*.

Topics in this chapter include:

- Overview of Static Host Mapping on page 45
- Configuring Static Host Mapping with the C-Web Interface on page 45

## Overview of Static Host Mapping

---

You can configure static host mapping to resolve hostnames. To configure static host mapping, you map the name to one or more IP addresses and aliases. Static host mapping supports both forward and reverse name lookups.

## Configuring Static Host Mapping with the C-Web Interface

---

To configure static host mapping:

1. Click **Configure**, expand **System**, and then click **Static Host Mapping**.

The Static Host Mapping pane appears.

2. From the Create new list, select **Static Host Mapping**.
3. Type the actual name for the static host in the dialog box, and click **OK**.

The Static Host Mapping pane appears.

4. Click **Create**, enter information as described in the Help text in the main pane, and then click **Apply**.

