

## Voice Interface Signals

<b>Pin</b>	<b>To/From Acorn</b>	<b>Description</b>	<b>Circuit</b>
1	---	Shield	
2	To	Channel 0 Voice RX - A (To CTP-1004)	Channel 0
3	From	Channel 0 Voice TX - A (From CTP-1004)	Channel 0
4	To	Channel 1 Voice Signaling Input A	Channel 1
5	From	Channel 1 Voice Signaling Output A	Channel 1
6	From	Channel 0 Voice Signaling Output A	Channel 0
9	From	Channel 1 Voice TX - A (From CTP-1004)	Channel 1
11	To	Channel 1 Voice RX - B (To CTP-1004)	Channel 1
13	From	Channel 1 Voice Signaling Output B	Channel 1
14	To	Channel 0 Voice RX - B (To CTP-1004)	Channel 0
16	From	Channel 0 Voice TX - B (From CTP-1004)	Channel 0
17	From	Channel 1 Voice TX - A (From CTP-1004)	Channel 1
19	To	Channel 1 Voice Signaling Input A	Channel 1
20	To	Channel 0 Voice Signaling Input A	Channel 0
22	From	Channel 0 Voice Signaling Output A	Channel 0
23	To	Channel 0 Voice Signaling Input B	Channel 0
24	To	Channel 1 Voice RX - A (To CTP-1004)	Channel 1